

Monitor Arm

Assembly Guide

Branch

The new way of working you've been waiting for.

Scan here for a digital copy
of your assembly guide.






Caution

- This product contains high-pressure gas springs. Do not put near high temperature areas, nor attempt an unauthorized disassembly. It may cause unpredictable personal injury.
- Make sure to read the entire manual before installation.
- Make sure the desktop can bear the weight of mount and monitor before installation.
- Use the supporting tools and the help of a friend when installing.
- Every six months, please make sure all bolts, screws, and knobs are fully tightened to ensure stability.
- If any parts are missing, broken, damaged, or worn, stop use of the product until repairs are made using factory-authorized parts.
- Failure to follow these warnings could result in serious injury.


Components




Clamp
x1



VESA Mounting Plate
x1



Clamp Arm
x1



VESA Arm
x1

VESA Screws (based on monitor size)



M4 Screws
x6



M5 Screws
x6

Adjustment Allen Keys



5mm Hex Key
x1




Phillips Head
4mm Hex Key
x1




3mm Hex Key
x1

1





For installation on open edge work surfaces, loosen the Clamp, attach to surface, and re-tighten. Be sure to twist the Clamp as tight as possible.

2




Insert the Clamp Arm into the Clamp. Then, insert the VESA Arm into the Clamp Arm. Make sure both arms are fully inserted (it may require a bit of force to put them into position), then simply tighten them in place with the 3mm Hex Key.

3



Attach the VESA Mounting Plate to your monitor of choice with either the M4 or M5 Screws. Then, slide the VESA Mounting Plate (with monitor attached) into the VESA Arm. To detach the monitor from the monitor arm, simply press the handle while lifting the VESA Mounting Plate from the VESA Arm.


4



Use the built-in cable clips on the VESA Arm as well as the cable tray on the Clamp Arm to help route the cables from your monitor to a power source. Simply detach the cable tray from the Clamp Arm by sliding it partially or fully off of the arm to insert your cables through, then slide it back on.


5

Adjust pitching angle
(5mm)



Adjust horizontal angle
(5mm)

Weight adjustment
(4mm)



Lastly, it's time to set your monitor up for proper placement! Follow the adjustment points above to loosen, position, and tighten your monitor arm such that your screen is about an arm's length away from your body, and the height of your monitor is at eye-level. You're now all set!

Contact

Have a question, comment, or suggestion?

hello@branchfurniture.com
branchfurniture.com

Branch